

■ BAND SEALERS

Information Only EMERGENCY STOP

****Always unplug the unit from the power source.****

Pls note that we have TWO versions of the emergency stop for the band sealer. Emergency stops look exactly the same except one is orange/orange and one is green/orange. Model #s are the same as well. Please note that these emergency stops are NOT interchangeable.



BS-22A_G



BS-22A_O



BS-22A_G




BS-22A_O




BS-22A_G



BS-22A_O



BS-22A_G



BS-22A_O