

HL-M810 Spare Parts Kit

We recommend the following spare parts for your HL-M810 band sealer

To order the full kit, use part# SPK-HL-M810

Part#		Description	Quantity
HL-M810-10		Sealing Belt	10
HL-M810-26		Drive Belt	4
INKROLLER-15-BLK		Black Ink Roller	2
BS-48A		Print Wheel	1
BS-52A		Speed PC Board	1
BS-50A		Ink Potentiometer PC Board	1
BS-52C		Main PC Board	1

BS-22A_O		Emergency Stop (Orange/Orange)	1
BS-22-LARGE		Switch (On/Off, Seal, Fan, Heat)	1
BS-59		Silicone Pin	2
BS-58		Ink Roller Holder	1
TS-AZ-18PT-HLM	Part # TS-NLS-18PT-HLM-FRM  Specify Letters, Numbers and/or Symbols Symbols: [], /, \, -, ., Blank	A-Z 18PT Typeset	1
TS-09-18PT-HLM	Part # TS-NLS-18PT-HLM-FRM  Specify Letters, Numbers and/or Symbols Symbols: [], /, \, -, ., Blank	0-9 18PT Typeset	1